



Thermocouple position for Outback and Alpha BBQs

1. Install the thermocouple sensor onto the thermocouple bracket
 - a. Thermocouple sensor is to be positioned horizontal to the burner with the tip approximately 4mm above the burner.



- b. Outback / Alpha – the tip of the sensor passes over the burner holes by 2mm.
 - c. Tighten the locking nuts using 2 x spanners to ensure it is locked tight into position.

